

|  |             |     |
|--|-------------|-----|
| LINCOLN SIT Function List(Note:For reference only)                                     |             |     |
| NOTES:   |             |     |
| ● This function is supported.  |             |     |
| ※ This function may be supported,which depends on the actual condition of the vehicle. |             |     |
| ○ This function is not supported.  |             |     |
| ▲ This function is the new feature in this version.                                    |             |     |
| Model  | Module Year | SIT |
| Aviator  | 2003-2005   | ●   |
| Continental  | 2017-2019   | ●   |
| LS   | 2000-2005   | ●   |
| Mark LT  | 2006-2008   | ●   |
| MKS  | 2009-2012   | ●   |
| MKS  | 2013-2016   | ●   |
| MKT  | 2010-2019   | ●   |
| MKX  | 2007-2010   | ●   |
| MKX  | 2011-2019   | ●   |
| MKZ  | 2007-2012   | ●   |
| MKZ  | 2013-2019   | ●   |
| Navigator  | 1999-2004   | ●   |
| Town Car   | 1995-2011   | ●   |
| Zephyr   | 2007-2012   | ●   |
| SIT Function List  |             |     |
| Passenger Seat Weight Sensor Resetting   |             |     |
| Driver's Seat Module   |             |     |
| Calibrate Power Seat   |             |     |
| Test Passenger Zero Seat Weight  |             |     |
| DSM Reset  |             |     |