

FORD BSC Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Module Year	BSC
B-Max	ALL	●
EcoSport	2013-2014	●
Fiesta	2008-2018	●
Focus Cabriolet	2006-2008	●
Focus C-MAX	2002-2014	●
Galaxy	2006-2014	●
Kuga	2008-2013	●
S-Max	2006-2014	●
Tourneo Connect	2009-	●
Transit	2006-2009	●
Focus	2000-2014	●
Mondeo	2004-2018	●
Transit Connect	2003-2019	●
Transit Courier	2001-2017	●

BSC Function List

ESP - Configure The Lateral Acceleration Sensor

ESP - Configure The Longitudinal Acceleration Sensor

ESP - Configure Yaw Rate Sensor

ESP - Pressure Sensor Calibration

ESP - Configure All Three Sensors Together

ESP - Configure The Pressure Sensor

ESP - Configure Both The Yaw Rate Sensor And The Lateral Acceleration Sensor

ESP - Disable Longitudinal Accelerometer Monitoring

ESP Sensor Calibration - Reset Pressure Sensor Offset

ESP Sensor Calibration - Calibrate Longitudinal Acceleration Sensor

ESP Sensor Calibration - Enable/Disable Hill Assist Function

ESP Sensor Calibration - Module Initialization