

CHRYSLER Diag Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Make	Year	Model
CHRYSLER	2017	200
CHRYSLER	2017	300
CHRYSLER	2017	Pacifica
CHRYSLER	2017	Town&Country
CHRYSLER	2016	200
CHRYSLER	2016	300
CHRYSLER	2016	Town&Country
CHRYSLER	2015	200
CHRYSLER	2015	300
CHRYSLER	2015	Town&Country
CHRYSLER	2014	200
CHRYSLER	2014	300
CHRYSLER	2014	Sebring
CHRYSLER	2014	Town&Country
CHRYSLER	2013	200
CHRYSLER	2013	300
CHRYSLER	2013	Sebring
CHRYSLER	2013	Town&Country
CHRYSLER	2012	200
CHRYSLER	2012	300
CHRYSLER	2012	Sebring
CHRYSLER	2012	Town&Country
CHRYSLER	2011	200
CHRYSLER	2011	300
CHRYSLER	2011	Sebring
CHRYSLER	2011	Town&Country
CHRYSLER	2010	200
CHRYSLER	2010	300
CHRYSLER	2010	PT Cruiser
CHRYSLER	2010	Sebring
CHRYSLER	2010	Town&Country
CHRYSLER	2009	200
CHRYSLER	2009	300
CHRYSLER	2009	Aspen
CHRYSLER	2009	PT Cruiser
CHRYSLER	2009	Sebring
CHRYSLER	2009	Town&Country
CHRYSLER	2008	200
CHRYSLER	2008	300
CHRYSLER	2008	Aspen
CHRYSLER	2008	Pacifica
CHRYSLER	2008	PT Cruiser
CHRYSLER	2008	Sebring
CHRYSLER	2008	Town&Country
CHRYSLER	2007	200
CHRYSLER	2007	300
CHRYSLER	2007	Aspen

CHRYSLER	2007	Grand Voyager		
CHRYSLER	2007	Pacifica		
CHRYSLER	2007	PT Cruiser		
CHRYSLER	2007	Sebring		
CHRYSLER	2007	Town&Country		
CHRYSLER	2006	300		
CHRYSLER	2006	Grand Voyager		
CHRYSLER	2006	Pacifica		
CHRYSLER	2006	PT Cruiser		
CHRYSLER	2006	Sebring		
CHRYSLER	2006	Town&Country		
CHRYSLER	2005	300		
CHRYSLER	2005	Grand Voyager		
CHRYSLER	2005	Pacifica		
CHRYSLER	2005	PT Cruiser		
CHRYSLER	2005	Sebring		
CHRYSLER	2005	Town&Country		
CHRYSLER	2004	300M		
CHRYSLER	2004	Concorde		
CHRYSLER	2004	Grand Voyager		
CHRYSLER	2004	Intrepid		
CHRYSLER	2004	Pacifica		
CHRYSLER	2004	PT Cruiser		
CHRYSLER	2004	Sebring		
CHRYSLER	2004	Town&Country		
CHRYSLER	Before 2004	Before 2004		
System	ECU INFO.	Read Code	Clear Code	View Data
PCM (Power Control Module)	●	●	●	●
PCM (Powertrain Control Module) (Type 1)	●	●	●	●
PCM (Powertrain Control Module) (Type 2)	●	●	●	●
RADIO	●	●	●	●
TCM (Transmission Control Module) (Type 1)	●	●	●	●
TCM (Transmission Control Module) (Type 2)	●	●	●	●
TCM (Transmission Control Module)	●	●	●	●
ABS (Antilock Brake Controller)	●	●	●	●
ORC/SRS (Occupant Restraint Controller)	●	●	●	●
BCM (Body Computer Module)	●	●	●	●
CCN/INSTR (Cabin Compartment Node/Instrument Cluster)	●	●	●	●
WCM (Wireless Control Module)	●	●	●	●
HVAC (Heat Ventilation And A/C)	●	●	●	●
OCM (Occupant Classification Module)	●	●	●	●
DDM (Drivers Door Module)	●	●	●	●
PDM (Passengers Door Module)	●	●	●	●
PTS (Park Tronics)	●	●	●	●
AMP (Amplifier)	●	●	●	●
ACC (Adaptive Cruise Control)	●	●	●	●
AHBM (Automatic High Beam Module)	●	●	●	●
DMFR (Door Module Front Right)	●	●	●	●
DMRR (Door Module Rear Right)	●	●	●	●
DVD (DVD Player)	●	●	●	●
ESM (Electronic Shifter Module)	●	●	●	●
FDCM (Final Drive Control Module)	●	●	●	●
EOM (Electronic Overhead Module)	●	●	●	●
HFM (Hands Free Module)	●	●	●	●
AHLM (Auto Headlamp Leveling Module)	●	●	●	●
ASBS (Automatic Sway Bar System)	●	●	●	●

AWD (All Wheel Drive)	●	●	●	●
DMFL (Left Forward Door Module)	●	●	●	●
DMRL (Left Rear Door Module)	●	●	●	●
FSM (Folding Seat Module)	●	●	●	●
HIDT (High Intensity Discharge Translator)	●	●	●	●
HSM (Heated Seat Module)	●	●	●	●
SAS (Steering Angle Sensor)	●	●	●	●
ITM (Intrusion Module)	●	●	●	●
LRSM (Light Rain Sensor Module)	●	●	●	●
PLGM (Power Lift Gate Module)	●	●	●	●
PSDML (Power Sliding Door Module (Left))	●	●	●	●
PSDMR (Power Sliding Door Module (Right))	●	●	●	●
PTIM (Police/Taxi Interface Module)	●	●	●	●
SDAR (Satellite Digital Radio)	●	●	●	●
SDARV (Satellite Video Receiver)	●	●	●	●
VES (Vehicle Entertainment System)	●	●	●	●
TM (Trailer)	●	●	●	●
MSMD (Memory Seat Module)	●	●	●	●
SUNR (Sunroof Module)	●	●	●	●
SCM (Steering Column Module)	●	●	●	●
VES3 (Last Row Srceem)	●	●	●	●
TPMS (Tire Pressure Monitoring Systems)	●	●	●	●
PTCM (Power Top Control Module)	●	●	●	●
PEM (Passive Entry Module)	●	●	●	●
VES2 (Second Row Screen)	●	●	●	●
SCCM (Steering Column Control Module)	●	●	●	●
IPC (Instrument Panel Cluster)	●	●	●	●
RFH (Radio Frequency Hub)	●	●	●	●
EPS (Electric Power Steering)	●	●	●	●
ICS (Integrated Center Stack)	●	●	●	●
BSM (Blind Spot Module)	●	●	●	●
TGW (Telematics Gateway)	●	●	●	●
VSIM (Vehicle System Interface Module)	●	●	●	●
ADCM (Active Damping Control Module)	●	●	●	●
AFLS (Adaptive Front Lighting System)	●	●	●	●
DTCM (Drive Train Control Module)	●	●	●	●
ASCM (Air Suspension Control Module)	●	●	●	●
CTM (Central Telematics Module)	●	●	●	●
CSWM (Comfort Seat And Wheel Module)	●	●	●	●
EDM (External Disc Module)	●	●	●	●
PAM (Park Assist Module)	●	●	●	●
LBSS (Left Blind Spot Sensor)	●	●	●	●
RBSS (Right Blind Spot Sensor)	●	●	●	●
DCU (Dosing Control Unit)	●	●	●	●
ELSD (Electronic Limited Slip Differential)	●	●	●	●
EPB (Electric Parking Brake)	●	●	●	●
EPPM (Electronic Pedestrian Protection Module)	●	●	●	●
ESL (Electronic Steering Lock)	●	●	●	●
FFCM (Forward Facing Camera Module)	●	●	●	●
VGT (Variable Geometry Turbo)	●	●	●	●
VTM (Vehicle Tracking Module)	●	●	●	●
PTU (Power Transfer Unit)	●	●	●	●
RDM (Rear Drive Module)	●	●	●	●
BPCM (Battery Pack Control Module)	●	●	●	●
BTM (Battery Thermal Module)	●	●	●	●
DISP (Front Display)	●	●	●	●

DRM (Data Recorder Module)	●	●	●	●
EAC (Electric A/C Compressor)	●	●	●	●
EBG (Electronic Booster Gauge)	●	●	●	●
HCP (Hybrid Control Processor)	●	●	●	●
HGM (Hybrid Gateway Module)	●	●	●	●
ITBM (Integrated Trailer Brake Module)	●	●	●	●
MCPA (Motor Control Processor A)	●	●	●	●
MCPB (Motor Control Processor B)	●	●	●	●
MSM (Memory Seat/Memory Heated Seat)	●	●	●	●
OBCM (On Board Charging Module)	●	●	●	●
PHGM (Plug In Hybrid Gateway Module)	●	●	●	●
ABSO (Anti Lock Brakes OBD)	●	●	●	●
AHCP (Auxiliary Hybrid Control Module)	●	●	●	●
AHM (Additional Heater Module)	●	●	●	●
ANC (Active Noise Cancelation)	●	●	●	●
APM (Adjustable Pedal Module)	●	●	●	●
CVPM (Central Vision Processing Module)	●	●	●	●
DSM (Display Screen Module)	●	●	●	●
DTV (Digital Television)	●	●	●	●
EAM (Emergency Assistance Module)	●	●	●	●
EBBM (Electronic Brake Booster Module)	●	●	●	●
EOMR (Electronic Overhead Module Rear)	●	●	●	●
ETM (Entertainment Telematic Module)	●	●	●	●
HALF (Haptical Lane Feedback)	●	●	●	●
HVACR (Rear Climate Control)	●	●	●	●
MSMP (Memory Seat Module-Passager)	●	●	●	●
RRM (Radio Receiver Module)	●	●	●	●
TTM (Trailer Tow Module)	●	●	●	●
VRM (Video Routing Module)	●	●	●	●
TBM (Telematic Box Module)	●	●	●	●
SRS (Supplemental Inflatable Restraint System)	●	●	●	●
HVAC/ATC	●	●	●	●
IPM/FCM (Intelligent Power Module)	●	●	●	●
MIC (Instrument Cluster)	●	●	●	●
MHS/APM (Memory Heated Seat/Adjustable Pedal Module)	●	●	●	●
DAA (Digital Audio Amplifier)	●	●	●	●
AT-XCM (Transfer Case Module)	●	●	●	●
NAV (NAVigation System)	●	●	●	●
RSM (Rain Sensor Module)	●	●	●	●
LSAB (Left Side Airbag)	●	●	●	●
RSAB (Right Side Airbag)	●	●	●	●
OHC (Overhead Console)	●	●	●	●
VTs (Vehicle Theft Security System)	●	●	●	●
SKM (SKIM-Skreem)	●	●	●	●
SAR (Satellite Audio Receiver)	●	●	●	●
SLA (Shift Level Assembly Module)	●	●	●	●
SRM (Airbag On/Off Switch System)	●	●	●	●